

# Pacific Truck & Trailer

## PARTS RECORD SHEETS TRUCK

CUSTOMER PERCY LOGGING MODEL P-16  
207 WEST HASTINGS SERIAL T-75118-900  
VANCOUVER, B.C. REQ. 5777  
 DELIVERED \_\_\_\_\_  
 WEIGHT 52980 (20360 TARE)  
 DEALER \_\_\_\_\_ DEALER DELIVERY \_\_\_\_\_

SECTION 1-ENGINE PARTS LIST 10-1600-01  
10-1601-01, 10-79, 10-75  
 MODEL GM 12V71 SERIAL 12VA045854 SPEC. 1068  
 FUEL PUMP INTERNAL SERIAL --  
 FAN 5189119 DIAMETER 36 MOUNT HIGH FAN BELTS 5133769  
 WATER PUMP BELT -- GENERATOR/ALTERNATOR BELT DAYCO 20-0773  
 QUICK START NIL CARTRIDGE NIL  
 FULL FLOW FILTER 5126546 ELEMENT --  
 BY-PASS FILTER 2126 ELEMENT -- BRACKET --  
 WATER CONDITIONER 4220-A ELEMENT (W) -- (A.F.) --  
 BLOCK HEATER NIL JACOBS BRAKE NIL PYROMETER R-624-10  
 AIR CLEANER SBG-140265 GAUGE RAX-002325 DIVERTER \_\_\_\_\_  
 EXHAUST 4" MUFFLER MOM-12-0100 GUARD MS-11 BRACKET \_\_\_\_\_  
 MISC. \_\_\_\_\_

CLUTCH PARTS LIST \_\_\_\_\_  
 MODEL \_\_\_\_\_  
 FORWARD DISC. \_\_\_\_\_ REAR DISC. \_\_\_\_\_  
 PILOT BEARING \_\_\_\_\_ THROW-OUT BEARING \_\_\_\_\_ YOKE \_\_\_\_\_  
 AIR ASSIST VALVE \_\_\_\_\_ CYLINDER \_\_\_\_\_  
 MISC. \_\_\_\_\_

SECTION 2 - MAIN TRANSMISSION PARTS LIST ALLISON & 20-40, 20-84  
 MODEL ALLISON CLBT-5960-6 SERIAL 681235G25 B/M. N<sup>o</sup>. 6882574  
 CLUTCH HOUSING #1 CONTROL WM-460-AC SHIFTER WM-445-A3-C SPEC. 2036  
 FLANGE or YOKE \_\_\_\_\_  
 MISC. MANUAL LOCK-UP

SECTION 3 - AUX. TRANSMISSION PARTS LIST \_\_\_\_\_  
 MODEL \_\_\_\_\_ SERIAL \_\_\_\_\_ B/M. N<sup>o</sup>. \_\_\_\_\_  
 CONTROL \_\_\_\_\_ SPEC. \_\_\_\_\_  
 FLANGE or YOKE (FWD.) \_\_\_\_\_ (REAR) \_\_\_\_\_  
 MISC. \_\_\_\_\_

### SECTION 4 - DRIVE LINES

MAIN to STDY. BEARING -- SERIES --  
 STDY. BEARING to AXLE -- SERIES -- RUN. LENGTH \_\_\_\_\_ TUBE \_\_\_\_\_  
 MAIN to AUX. 200771-13 SERIES 1800 RUN. LENGTH 28 1/4 TUBE 34 5/8  
 AUX. to AXLE 904848 SERIES 1810 RUN. LENGTH 63 1/4 TUBE 38 1/4  
 INTER-AXLE 906354 SERIES 1710 RUN. LENGTH 35 1/4 TUBE 15 1/2

### SECTION 5 - PARKING BRAKE

PARTS LIST MAXI  
 MAKE MAXI TYPE 36-75 MODEL 47-40120-9 CAMTITE II  
 VALVE WM-325  
 MISC. \_\_\_\_\_

## PARTS RECORD SHEETS- TRUCK

 MODEL P-16  
 SERIAL T-75118-900

 SECTION 6 - STEERING PARTS LIST 60-1600-03  
 MODEL GEMMER XG-500 POWER ASSIST VICKERS  
 PUMP V210-8W-1C-D6-12S-138 LH BOOSTER S20-B22-2BAX-NN-12N-11  
 DRIVEN PULLEY 2BK-62-H BELTB-39 SIGHT GAUGE UC-1215  
 RESERVOIR RH-10 BREATHER A1199-J-166 FILTER OFM-101 DROP ARM DA-5  
 MISC. \_\_\_\_\_

 SECTION 7 - FRONT AXLE PARTS LIST 70-14  
 MAKE TIMKEN MODEL FU-910-PX-21 SERIAL N143725 SPEC. 7043  
 TRACK 89 B.C. \_\_\_\_\_ K.P. CENTRES \_\_\_\_\_ SPRING CENTRES --  
 HUBS NIL BRAKES 20 1/4 x 5  
 WHEEL STUDS (L.H.) NIL CAPNUTS (L.H.) NIL  
 (R.H.) NIL (R.H.) NIL  
 FRONT SPRINGS (L.H.) S-81 (R.H.) S-81 SUSPENSION PACIFIC  
 MISC. \_\_\_\_\_

 SECTION 8 - REAR AXLE PARTS LIST 80-51  
 MAKE CLARK MODEL BD-91,000 RATIO 13,298:1 SPEC. 8041  
 FWD AXLE 192295 SERIAL 438016  
 REAR AXLE 191685 SERIAL 440928  
 FWD. CARRIER 124293 REAR CARRIER 124311  
 AXLE SPACING 70 TRACK 100 B.C. \_\_\_\_\_ TORQUE ROD LENGTH \_\_\_\_\_  
 HUBS 124302 DRUMS 120925 LINING KIT SEE CLARK LIST  
 STUDS (L.H.) NIL NUTS-INNER (L.H.) NIL OUTER (L.H.) NIL  
 (R.H.) NIL (R.H.) NIL (R.H.) NIL  
 RIM CLAMPS 107660 STUDS 110036 NUTS 360398  
 BRAKE SIZE 20x7 CHAMBERS (FWD) MAXI (REAR) MAXI  
 SUSPENSION PACIFIC SPRINGS S-98 PADS TSP-60 U-BOLTS UB-72  
 FLANGE or YOKE - FRONT of FORWARD AXLE YOKE - 123223  
 REAR of FORWARD AXLE YOKE - 109604  
 FRONT of REAR AXLE YOKE - 124348  
 MISC. \_\_\_\_\_

 SECTION 9 - TIRES & WHEELS  
 FRONT GOODYEAR SIZE 1400 x 25 TREAD RIB  
 REAR UNIROYAL SIZE 1400 x 25 TREAD SUPER CONTRACTOR  
 WHEELS-FRONT DAYTON 08269 REAR GOODYEAR 1025 TD RIMS  
 RIMS GOODYEAR 1025-TD SPACERS SG-1389

 SECTION 10 - FRAME PARTS LIST 100-172  
 MODEL FLR-90000 R & P W.B. 236 RAILS \_\_\_\_\_  
 BUMPER CMR-1-AP BUMPER PIN PX-149 BRUSHGUARD GR-31  
 REAR CROSSMEMBER CMR-7-BG  
 MISC. COMPENSATOR CR-23 - Bushings B91-24

 SECTION 11 - COOLING SYSTEM PARTS LIST 110-1600-01  
 RADIATOR ASSEMBLY AR-32 CAPACITY \_\_\_\_\_  
 SHUTTER 1045-04623-01 SHROUD SRF-97  
 SHUTTERSTAT -- SHUTTER CYLINDER --  
 WATER CONNECTOR (TOP) WC-49 (BOTTOM) WC-37 (ENGINE) WC-61  
 HOSE (TOP) GREEN STRIPE 2 1/2" (BOTTOM) GREEN STRIPE 3 1/2"  
 WATER OUTLET COVER (TOP TANK) --  
 MISC. \_\_\_\_\_

## PARTS RECORD SHEETS - TRUCK

 MODEL P-16  
 SERIAL T-75118-900

SECTION 12 - ELECTRICAL		PARTS LIST 120-107	
SYSTEM	<u>24 VOLT</u>	GROUND	<u>NEGATIVE</u>
BATTERIES	<u>4-6 VOLT GR-5-D</u>		
GENERATOR/ALTERNATOR	<u>1117238</u>	SERIAL	<u>75K20</u>
STARTER	<u>1109979</u>	SERIAL	<u>73M05</u>
REGULATOR	<u>HEATER SWITCH</u>		
IGNITION SWITCH	<u>307-E</u>	START BUTTON	<u>627670</u>
DIMMER SWITCH	<u>76-5136</u>	TOGGLE SWITCHES	<u>571 &amp; 577</u>
MASTER SWITCH	<u>1996471</u>	STOP LIGHT SWITCH	<u>223220</u>
DASH LIGHT SWITCH	<u>60238</u>	DASH WARNING LIGHTS	<u>31-3504-1331-301</u>
CIRCUIT BREAKERS	<u>CDM-20 &amp; CDLM-50</u>		
ACCESSORY RELAY	<u>STOP &amp; TAIL LIGHTS</u>		
CAB MARKER LIGHTS	<u>71-4025</u>	STOP & TAIL LIGHTS	<u>70-2609</u>
CLEARANCE LIGHTS	<u>--</u>	REFLECTORS(RED)	<u>-- (AMBER) --</u>
HEADLIGHTS	<u>72-5507</u>	SEALED BEAMS	<u>4800-24V</u>
BACK-UP LIGHT	<u>--</u>	LAMP	<u>--</u>
DUAL HEADLIGHTS (L.H.)	<u>--</u>	(R.H.)	<u>--</u>
(DOORS)	<u>--</u>		
DUAL HEADLIGHT SEALED BEAMS;(HIGH BEAM)	<u>--</u>	(LOW BEAM)	<u>--</u>
TURN SIGNAL LIGHTS	<u>--</u>	SIGNALSTAT	<u>--</u>
FLASHER	<u>--</u>		
DRIVING LIGHTS	<u>--</u>	LAMP	<u>--</u>
LOADING LIGHTS	<u>72-5018</u>	LAMP	<u>--</u>
HIGH BEAM INDICATOR	<u>PL-1</u>	ELECTRIC HORN	<u>--</u>
LIGHTER	<u>60149</u>	HEATER	<u>R-5710-PT</u>
FAN	<u>50234</u>	TRAILER PLUG	<u>--</u>
DOME LIGHT	<u>72-2801</u>	FLASHER LIGHT	<u>70-6063</u>
FLASHER	<u>74-3005</u>		
MISC.	<u>ENGINE STOP BUTTON PMA-611</u>		

SECTION 13 - AIR EQUIPMENT		PARTS LIST 130-52	
SCHEDULE	<u>"B" TWO COMPRESSORS</u>	CFM	<u>13.5</u>
COMPRESSOR (F)	<u>--</u>	(R)	<u>--</u>
BELTS (F)	<u>--</u>	(R)	<u>--</u>
RESERVOIR	<u>221340</u>	DRAIN COCK	<u>215310</u>
MANIFOLD	<u>212322</u>		
GOVERNOR (P.S.I.85-105 )	<u>275200</u>	GOVERNOR (LOW PRESS	<u>55-60</u>
P.S.I.)	<u>275200</u>		
FRONT AXLE BRAKE VALVE	<u>275107</u>	QUICK RELEASE VALVE (F.A.)	<u>205000</u>
HAND VALVE (TRAILER)	<u>275107</u>	FOOT VALVE	<u>275000</u>
DOUBLE CHECK VALVE	<u>223869</u>	SINGLE CHECK VALVE	<u>223891</u>
TRACTOR EMERGENCY	<u>EV-1000</u>	QUICK RELEASE (REAR AXLES)	<u>205000</u>
BOOSTER PROTECTION	<u>BCP-56</u>	LOW PRESSURE INDICATOR	<u>--</u>
EMERGENCY	<u>WM-321</u>	EMERGENCY DUMP	<u>WM-147-BC</u>
SAFETY VALVE	<u>205105</u>	TRACTOR PROTECTION RELAY	<u>WM-57</u>
GLAD HAND	<u>220165</u>	ANCHOR COUPLINGS	<u>205465 &amp; 205730</u>
HORN	<u>GROVER 1024</u>	HORN VALVE	<u>1630</u>
PRESS. VALVE (WATER)	<u>--</u>		
AIR DRYER	<u>NIL</u>		
MISC.	<u>STOPLIGHT SWITCH BRACKET BX-1327</u>		

SECTION 14 - INSTRUMENTS		PARTS LIST 140-63	
SPEEDOMETER	<u>550-ET</u>	ADAPTER	<u>777-B</u>
RATIO	<u>4186</u>	CABLE	<u>--</u>
TACHOMETER	<u>551-ACP</u>	ADAPTER	<u>--</u>
RATIO	<u>--</u>	CABLE	<u>--</u>
SPEEDOGRAPH	<u>--</u>	TACHOGRAPH	<u>--</u>
COMBINATION	<u>--</u>		
AMMETER	<u>338-AW</u>	AIR PRESS. GAUGE	<u>691-FB</u>
EMERGENCY GAUGE	<u>490-AD</u>		
TEMP. GAUGE (OIL)	<u>361-CC-144</u>	TEMP. GAUGE (WATER)	<u>491-AR-144</u>
SWITCH	<u>SENDING UNITS</u>		
TEMP. GAUGE TRANS.	<u>465-B</u>	AXLE	<u>--</u>
SENDING UNITS	<u>334-5</u>		
FUEL GAUGE	<u>--</u>	VACUUM GAUGE	<u>--</u>
PRESSURE GAUGE	<u>--</u>		
ENGINE OIL PRESSURE GAUGE	<u>490-AZ</u>	SWITCH	<u>--</u>
WIPER MOTORS	<u>FPDP-80R &amp; L</u>	SHAFT	<u>F-1160-3J</u>
PLATE	<u>F-1043-3J</u>		
WIPER VALVE	<u>F-1650-6NS</u>	ARMS	<u>80910-71-JL-12</u>
BLADE	<u>M874-44TM14</u>		
WINDSHIELD WASHER ASSY.	<u>89CP (VALVE)</u>	BRACKET	<u>--</u>
DASH PANEL	<u>DP-8</u>	INSERT	<u>DP-5</u>
SWITCH PANEL	<u>--</u>		
MISC.	<u>IDLER CONTROL D-43582-72"</u>		

## PARTS RECORD SHEETS-TRUCK

 MODEL P-16  
 SERIAL T-75118-900


---

**SECTION 15 - FUEL SYSTEM** PARTS LIST 150-1600-01  
 FUEL TANK FT-27 CAPACITY 100 GAL MOUNTED Front of Water Tank  
 FUEL FILTER (PRIMARY) -- (SECONDARY) --  
 ELEMENT (PRIMARY) -- (SECONDARY) --  
 FLOAT TANK -- FUEL/WATER SEPERATOR CM-99-217B  
 MISC. \_\_\_\_\_

(Customer Parts List Revised) 160-1600-02 160-1603-01  
 160-1601-02 160-1607-01  
 160-1608-01

**SECTION 16 - CAB** PARTS LIST  
 MODEL C-26  
 WINDSHIELD GWC-32 REAR WINDOW (SLIDING) 410769-C91 (FIXED) NIL  
 DOOR (L.H.) 403008C92 (R.H.) 403009C92 DOOR GLASS 403510C1  
 VENT WINDOWS 403505C91 & 403506C91 VENT WINDOW GLASS --  
 DRIVERS SEAT 42693-1A RISER PM-12 BELT ASSY. --  
 SWAMPERS SEAT 42104-1 RISER TBX-2 BELT ASSY. --  
 INSULATION PANEL PA-6 & PA-40 FLOOR MAT C25-FM SUN VISOR VS-6  
 MIRROR HEADS 75-4407 BRACKETS (LH) BX-1516-A (R.H.) BX-1089-B  
 CAB LINING CLC-22 DOOR LINING CLC-25  
 MISC. \_\_\_\_\_

**SECTION 17 - HOOD & FENDERS** PARTS LIST 170-1600-01  
 HOOD HE-88 FENDER (LH) F-49-A (RH) F-49-B  
 DUAL HEADLIGHT BRACKETS -- MUD FLAPS GU-13  
 MISC. \_\_\_\_\_

**SECTION 18 - PAINT**  
 CAB #2150 RED WITH WHITE TOP & 3" WHITE STRIPE AROUND CAB  
 FRAME RED FENDERS RED  
 HOOD (TOP) RED (SIDES) RED WITH 3" WHITE STRIPE  
 BUMPER RED GRILLE GUARD WHITE WHEELS WHITE  
 MISC. \_\_\_\_\_

**SECTION 19 - ACCESSORIES**  
 WHEEL WRENCH 199-F WRENCH HANDLE 199-H  
 \_\_\_\_\_  
 \_\_\_\_\_

**SECTION 20 - LOGGING EQUIPMENT** PARTS LIST 200-226  
 SUBFRAME & BOLSTER -- CAB PROTECTOR --  
 TRAILER REST -- TRAILER RAMP -- WATER TANK WF-57  
 BUNK ASSEMBLY BUA-126-13 BUNK STAKES SZ-72-Y CABLE BCA-19-13  
 REACH REST RS-29 COMPENSATOR CR-23 LOCK BX-517 OIL BATH \_\_\_\_\_  
 MISC. \_\_\_\_\_  
 \_\_\_\_\_  
 \_\_\_\_\_

**NOTE**

When ordering parts for your PACIFIC TRUCK please supply the following information

MODEL NO. \_\_\_\_\_

SERIAL NO. \_\_\_\_\_