



PARTS RECORD SHEETS  
TRUCK

CUSTOMER NORTH SHORE CONTRACTING LTD. MODEL P-16  
#507-207 WEST HASTINGS ST. SERIAL T-76118-941  
VANCOUVER, B.C. REQ. 5862  
 DELIVERED \_\_\_\_\_  
 WEIGHT \_\_\_\_\_  
 DEALER PACIFIC TRUCK & TRAILER LTD. DEALER DELIVERY --

SECTION 10 - ENGINE

MODEL GM 12V71-7127 SERIAL 12VA049944 SPEC. 1068  
 FUEL PUMP INTERNAL SERIAL --  
 BELTS- FAN 5133789 WATER PUMP -- GEN./ALT. 20-0773  
 ELEMENTS- FULL FLOW 5126546 BY-PASS \_\_\_\_\_ WATER 4220-A

ILLUSTRATIONS & PARTS LISTS

ENGINE	_____	PL-10-1600-01
ENGINE INSTALLATION	<u>ILL-10-1601-01</u>	<u>PL-10-1601-01</u>
CLUTCH	_____	_____
AIR ASSIST	_____	_____
ENGINE BRAKE	_____	_____
BLOCK HEATER	_____	<u>PL-10-1604-02</u>
OIL PAN HEATER	_____	_____
EXHAUST PYROMETER	_____	_____
THERMATIC FAN	_____	_____
AIR CLEANER	<u>ILL-10-1608-01</u>	<u>PL-10-1608-01</u>
AIR DIVERTER	_____	_____
VACUUM GAUGE	_____	_____
AIR CLEANER- CHROME	_____	_____
HAND THROTTLE	_____	<u>PL-10-1609-01</u>
LIGHT, ALARM &/or SHUTDOWN	_____	<u>PL-10-1610-01</u>
LUBE OIL FILTER	_____	<u>PL-10-1611-02</u>
CHROME OIL FILTER	_____	_____
STARTING AID	_____	_____
EXHAUST	<u>ILL-10-1613-04</u>	<u>PL-10-1613-04</u>
EXHAUST- CHROME	_____	_____
WATER CONDITIONER	_____	<u>PL-10-1614-01</u>
AIR STARTER	_____	_____

SECTION 20- MAIN TRANSMISSION

MODEL ALLISON 5960-6 SERIAL 71416-6G15 B/M N° 6882574 SPEC. 2036

ILLUSTRATIONS & PARTS LISTS

TRANSMISSION	_____	PL-20-1600-01
TRANS. INSTALLATION	<u>ILL-20-1601-01</u>	<u>PL-20-1601-01</u>
CLUTCH CONTROLS	_____	_____
POWER TAKE-OFF	_____	_____

MODEL P-16  
 SERIAL T-76118-941
SECTION 20 - MAIN TRANSMISSION (CONTINUED)

MAGNETIC OIL PLUG	_____	PL-20-1605-01
MANUAL LOCK-UP	_____	PL-20-1604-01
FRONT AXLE CONTROL	_____	_____
	_____	_____

SECTION 30 - AUXILLIARY TRANSMISSION
 MODEL NIL SERIAL NIL B/M N° NIL SPEC NIL
ILLUSTRATIONS & PARTS LISTS

TRANSMISSION	__	__
TRANS. INSTALLATION	__	__
POWER TAKE-OFF	__	__
	__	__
	__	__

SECTION 40 - DRIVE LINES
 RUNNING LENGTH-(FWD) 28 1/4" F-F (INTERMEDIATE) 62 1/2" F-Y  
 (INTER-AXLE) 36 1/4" Y-Y (ADD. STEADY BEARING) \_\_\_\_\_
ILLUSTRATIONS & PARTS LISTS

FORWARD	( 1810 )	ILL-40-1600-03	PL-40-1600-03
INTERMEDIATE	( 1810 )	ILL-40-1601-01	PL-40-1601-01
INTER-AXLE	( 1710 )	ILL-40-1602-01	PL-40-1602-01
ADD. STEADY BRG.	( )	_____	_____
FRONT AXLE	( )	_____	_____

SECTION 50 - PARKING BRAKE
 MODEL MAXI - TYPE 36 QTY TWO AXLES (4)
ILLUSTRATIONS & PARTS LISTS

PARKING BRAKE	ILL-50-1600-04	PL-50-1600-04
WARNING LIGHT	_____	_____

SECTION 60 - STEERING
 MODEL GEMMER XG-500
ILLUSTRATIONS & PARTS LISTS

STEERING INSTALLATION	ILL-60-1600-04	PL-60-1600-04
-----------------------	----------------	---------------

SECTION 70 - FRONT AXLE
 MODEL TIMKEN FU-910-PX-21 SERIAL N242590 SPEC 7043  
 TRACK 89" BRAKE SIZE 20 1/4" x 5"
ILLUSTRATIONS & PARTS LISTS

FRONT AXLE	_____	PL-70-1600-01
WHEELS	_____	PL-70-1601-01
RIMS	_____	PL-70-1602-03
OIL SEALS	_____	_____
SUSPENSION	_____	PL-70-1604-01
SHOCK ABSORBERS	_____	_____
FRONT AXLE BREATHER	_____	_____
	_____	_____

MODEL P-16SERIAL T-76118-941SECTION 80 - REAR AXLE

MODEL CLARK BD-91,000 RATIO 13.298-1 SPEC 8041  
 TRACK 100" BRAKE SIZE 20x7 AXLE SPACING 70  
 FORWARD AXLE 192295 SERIAL 472979  
 REAR AXLE 191685 SERIAL 472974  
 FWD CARRIER 124293 REAR CARRIER 124311

ILLUSTRATIONS & PARTS LISTS

REAR AXLES	_____	<u>PL-80-1600-02</u>
WHEELS	_____	
RIMS	_____	<u>PL-80-1602-04</u>
OIL SEALS	_____	
INTER-AXLE DIFF.	_____	
REMOTE AXLE BREATHER	_____	
MAGNETIC OIL PLUG	_____	
TWO SPEED CONTROL	_____	
SUSPENSION	<u>ILL-80-1607-02</u>	<u>PL-80-1607-02</u>
STEERING YOKE	_____	
SHOCK ABSORBERS	_____	

SECTION 90 - TIRES

FRONT MICHELIN SIZE 1400x25-20 PLY TREAD XRD-1-B  
 REAR B.F. GOODRICH SIZE 1400x25-20 PLY TREAD R.S.H.T.

SECTION 100 - FRAME

FRAME LAYOUT FLR-91,000-I & C W.B. 236 " C.A. 132 1/2" A.F. 90"

ILLUSTRATIONS & PARTS LISTS

FRAME	<u>ILL-100-1600-07</u>	<u>PL-100-1600-07</u>
BUMPER	<u>ILL-100-1610-04</u>	<u>PL-100-1610-04</u>
GRILL GUARD	<u>ILL-100-1611-01</u>	<u>PL-100-1611-01</u>
REAR CROSSMEMBER	<u>ILL-100-1613-02</u>	<u>PL-100-1613-02</u>
TOW HITCH	_____	
TOW HOOKS	_____	

SECTION 110 - COOLING SYSTEM

RADIATOR ASSEMBLY AR32

ILLUSTRATIONS & PARTS LISTS

RADIATOR INSTALLATION ILL-110-1600-01 PL-110-1600-01

SECTION 120 - ELECTRICAL

SYSTEM 24 VOLT GROUND NEGATIVE BATTERIES 4-6V GR7D  
 ALTERNATOR DELCO REMY 1117249 SERIAL 76C12  
 STARTER DELCO REMY 1109979 SERIAL 76D29 REGULATOR --

MODEL P-16

SERIAL T-76118-941

SECTION 120 - ELECTRICAL (CONTINUED)

ILLUSTRATIONS & PARTS LISTS

CAB ELECTRICAL	_____	PL-120-1600-01
FRAME ELECTRICAL	_____	PL-120-1600-02
ALTERNATOR INSTALLATION	_____	PL-120-1601-01
CAB MARKER LIGHTS	_____	PL-120-1602-01
BATTERY INSTALLATION	<u>ILL-120-1603-02</u>	PL-120-1603-02
ISOLATION SWITCH	_____	PL-120-1604-01
HEADLIGHTS	_____	PL-120-1605-01
TURN INDICATORS	_____	_____
ELECTRIC HORN	_____	_____
BACK-UP LIGHT	_____	PL-120-1608-01
DRIVING LIGHT	_____	_____
SPOT LIGHT	_____	_____
WARNING FLASHER	_____	PL-120-1611-03
TRAILER CONNECTION	_____	_____
RADIO	_____	_____

SECTION 130 - AIR SYSTEM

SCHEDULE L-75 TWO COMPRESSOR @ 12 C.F.M.  
 FWD. COMPRESSOR 283390 BELT 5145730  
 REAR COMPRESSOR 285923 BELT 8114-2212

ILLUSTRATIONS & PARTS LISTS

AIR SYSTEM INSTALLATION	<u>ILL-130-1600-03</u>	PL-130-1600-03
COMPRESSOR	_____	PL-130-1601-01
FRONT AXLE BRAKES	_____	PL-130-1602-01
ALCOHOL EVAPORATOR	_____	_____
MOISTURE EJECTION VALVE	_____	_____
AIR DRYER	_____	_____
WIG WAG &/or IND. LIGHT	_____	PL-130-1606-02
AIR HORN	_____	PL-130-1607-01
SNOW SHIELD	_____	_____
TRAILER AIR CONNECTOR	_____	_____
AIR MISC EQUIPMENT	_____	_____

SECTION 140 - INSTRUMENTS

SPEEDOMETER ADAPTER 777B RATIO .3882

ILLUSTRATIONS & PARTS LISTS

BASIC INSTRUMENTS	_____	PL-140-1600-03
TACHOMETER	_____	PL-140-1601-02
SPEEDOMETER	_____	PL-140-1602-04
TRANS. TEMP. GAUGE	_____	_____
AXLE TEMP. GAUGE	_____	_____
HEATER	_____	PL-140-1605-01
AIR CONDITIONER	_____	_____

MODEL P-16SERIAL T-76118-941SECTION 140 - INSTRUMENTS (CONTINUED)

WINDSHIELD WIPERS	_____	PL-140-1607-01
WINDSHIELD WASHERS	_____	PL-140-1608-01
ENGINE HOUR METER	_____	PL-140-1609-01
EXTRA DEFROSTER FAN	_____	_____
OIL PRESSURE GAUGE	_____	PL-140-1611-01
	_____	_____
	_____	_____

SECTION 150 - FUEL SYSTEMILLUSTRATIONS & PARTS LISTS

FUEL TANK INSTALLATION	<u>ILL-150-1600-02</u>	<u>PL-150-1600-02</u>
FUEL GAUGE	_____	<u>PL-150-1601-02</u>
FUEL/WATER SEPARATOR	_____	_____
FUEL VACUUM/PRESS. GAUGE	_____	_____
FUEL FILTER	_____	_____
CHROME	_____	_____
	_____	_____
	_____	_____

SECTION 160 - CABMODEL C-31 OFFSETILLUSTRATIONS & PARTS LISTS

CAB	_____	_____
CAB TRIM	<u>ILL-160-1600-05</u>	<u>PL-160-1600-05</u>
DOOR TRIM	<u>ILL-160-1601-02</u>	<u>PL-160-1601-02</u>
ELECTRIC WINDOW R.H.	_____	_____
SOUND PROOFING	_____	_____
CAB INSTALLATION	<u>ILL-160-1603-01</u>	<u>PL-160-1603-01</u>
DRIVERS SEAT	_____	<u>PL-160-1604-01</u>
SWAMPERS SEAT	_____	<u>PL-160-1605-01</u>
TOOL BOX	_____	<u>PL-160-1606-01</u>
MIRROR	<u>ILL-160-1607-05</u>	<u>PL-160-1607-05</u>
ADDITIONAL MIRROR	_____	<u>PL-160-1607-03</u>
REAR WINDOW	_____	<u>PL-160-1608-01</u>
PROTECTION SCREEN	_____	_____
SUN VISOR- INTERIOR	_____	<u>PL-160-1610-01</u>
SUN VISOR- EXTERIOR	_____	_____
SUN ROOF	_____	_____
SEAT BELTS	_____	_____
	_____	_____
	_____	_____

SECTION 170 - HOOD & FENDERSILLUSTRATIONS & PARTS LISTS

HOOD & FENDERS INST.	<u>ILL-170-1600-04</u>	<u>PL-170-1600-04</u>
	_____	_____
	_____	_____

PARTS RECORD SHEETS- TRUCK

MODEL P-16

SERIAL T-76118-941

SECTION 180 - PAINT

CAB	230 YELLOW (4321-1033)	FRAME	230 YELLOW (4321-1033)
		FENDERS	230 YELLOW (4321-1033)
		BUMPER	230 YELLOW (4321-1033)
HOOD TOP	GREEN 2331-8008	GRILLE GUARD	230 YELLOW (4321-1033)
HOOD SIDES	230 YELLOW (4321-1033)	WHEELS	230 YELLOW (4321-1033)
TRIM			

SECTION 190 - ACCESSORIES

ILLUSTRATIONS & PARTS LISTS

ACCESSORIES & SERVICE	_____	PL-190-1600-01
LUBRICATION	_____	PL-190-1601-01
WHEEL WRENCH & HANDLE	_____	PL-190-1602-01
MUD FLAPS	_____	_____
FIRE EXTINGUISHER	_____	_____
FLAGS & FLARES	_____	_____
HYDRAULIC JACK	_____	_____
TOOL KIT & GREASE GUN	_____	_____
REAR FENDERS	_____	_____
REAR DECK	_____	_____
WATER TANK WALKWAY	_____	_____
	_____	_____
	_____	_____

SECTION

MODEL P-16

SERIAL T-76118-941

SECTION 200 - LOGGING EQUIPMENT

POWER TAKE-OFF - MODEL \_\_\_\_\_ SERIAL \_\_\_\_\_

HYDRAULIC PUMP - MODEL \_\_\_\_\_ SERIAL \_\_\_\_\_

WINCH - MODEL \_\_\_\_\_ SERIAL \_\_\_\_\_

ILLUSTRATIONS & PARTS LISTS

WATER TANK	<u>ILL-200-1600-06</u>	<u>PL-200-1600-06</u>
WATER LINES	_____	<u>PL-200-1600-21</u>
CAB PROTECTOR	_____	_____
SUBFRAME BASKET	_____	_____
REACH SADDLE	<u>ILL-200-1603-01</u>	<u>PL-200-1603-01</u>
SUBFRAME & BOLSTER	_____	_____
TRAILER RAMPS	_____	_____
PRELOAD EQUIPMENT	_____	_____
BUNK	<u>ILL-200-1607-03</u>	<u>PL-200-1607-03</u>
BUNK ROLLERS	<u>ILL-200-1608-01</u>	<u>PL-200-1608-01</u>
TURNTABLES	<u>ILL-200-1609-01</u>	<u>PL-200-1609-01</u>
WINCH INSTALLATION	_____	_____
P.T.O. INSTALLATION	_____	_____
HYDRAULIC EQUIPMENT	_____	_____

MISC.

\_\_\_\_\_

\_\_\_\_\_

\_\_\_\_\_

\_\_\_\_\_

\_\_\_\_\_

\_\_\_\_\_

\_\_\_\_\_